When raising the penetrating force

●Corrective action by program mode

Mode name	Function name		rect call numb	Operability	Factory setting (GMFY)	Setting	Specification	Approach
	Revarse run needle lifting after thread trimming	RU.	0036	0	OF	ON OF	The motor is reverse run after thread trimming, and the needle will stop near the needle bar top dead point.	Turn on (Reverse needle giving)
А	Gain high/low selection	GA.	0100	0	L	ΙυЦ		To setting with H (There is a case that noise comes out.)
	Operation gain for the big inertia sewing machine	HWG.	1260	0	OF		Operation gain for the big inertia sewing machine is valid.	Turn on