


## Adjustment of the presser foot pressure (Compound Feed)

Adjust the presser foot pressure according to the fabric by turning the pressure adjusting screw.



## Adjustment of the presser foot pressure (Upper and Lower Feed)

1. Adjust the presser foot pressure according to the fabric by turning the pressure adjusting screw.
2. Pressure on the both the presser foot and the feed foot can be adjusted. (The adjusting screw position is factory-adjusted as shown in the figure.)
3. Sewing pressure should be adjusted to the minimum required strength.

