


Adjustment of needle threads tension (Compound Feed)

- Needle threads tension should be adjusted on the basis of bobbin threads tension.
- Adjust needle threads tension by turning thread tension nuts.

Needle threads tension can be also adjusted by changing intensity and movable range of the thread take-up spring in case of sewing the special fabric and thread.



Adjustment of the needle thread tension (Upper and Lower Feed)

- The needle thread tension should be adjusted on the basis of the bobbin thread tension.
- Adjust the needle thread tension by turning the thread tension nut.

The needle thread tension can be also adjusted by changing intensity and movable range of the thread take-up spring in case of sewing the special fabric and thread.

