


■Setting file read


(1)Entering the function mode

- ▶ Press  and  on the Standard screen, and open the Function Mode screen.



(2)Function mode screen


- ▶ Press .



(3)Reading setting file

- ▶ Insert USB memory where the sewing data is preserved to the connector.

- ▶ Press , then press .



(4)Selecting setting file

- ▶ **Select** setting file by using up and down arrow, then press



MEMO Reading is proceeded by overwrite mode. Original setting data will be erased.

- ▶ When message like as [Please turn the power supply off] is displayed, follow the instruction.

