

Installation of the tilting detect switch

(1) Install the switch units (No.1) with the SW-MW screws (No.2) so that the switch turns on when the machine head in initial position is pushed by the machine table.

[Notice] if the switch is not turned on, error [M-038] will occur.

<1>: Switch units

<2>: SW-MW screw (two screws)

