

DDL-8000CS SUPER SHORT THREAD REMAIN KIT INSTRUCTION MANUAL



(1) List of components that come with the super short thread remain spacer

Part number of the super short thread remain spacer : 40309300 • List of parts supplied with the machine

No.	Description	Parts No.	Qty
4	Thread trimming knife spacer	40309298	1
1	Moving knife spacer	40309299	1

(2) Installation

No.	Description	Parts No.
0	Knife setscrew	40263580
9	Thread trimming knife set-	40264700
	screw	
3	Thread trimming knife	40263570
4	Thread trimming knife spacer	40309298
6	Thread trimming knife base	40263570

No.	Description	Parts No.
6	Moving knife	40263579
7	Moving knife spacer	40309299
8	Moving knife base	40263575

Loosen knife setscrews **1** and thread trimming knife setscrew **2**. Remove thread trimming knife **3** and moving knife **6**.

Place spacers ④ and ⑦ respectively between thread trimming knife ⑤ and thread trimming knife ⑤ and between moving knife ⑥ and moving knife ⑤ as ⑧.

Then, secure the knives with knife setscrews 1 and thread trimming knife setscrew 2.

* Tightening torque: 1.5 to 2.0 N·m (15 to 20 kgf·cm)

(3) Checking after the installation

Operate the thread trimming mechanism manually to make sure that there is no interference between the related parts before use.