

Waistband Shadow Stitch Sewing Unit

JTR-DLN9010/WSU

PARTS LIST



No.JTR000
DLN9010WSU-SP

HOW TO MAKE USE OF THIS PARTS LIST

1. Explanation of codes

- 1) "*" mark means this part is consumption part.
- 2) "#01 " refer to "Note" explanation at bottom of page.
- 3) "☆" means this part is replaced from Juki Original part to Jtron Original part.

2. Codes on the "Qty" column

- Each numeral indicates the number of parts required.
- "0.1" and "2.5" indicate the length (in meters) of the respective parts.


3. Parentheses mean that the corresponding part is a subpart that constructs an assembly part.

4. Dotted lines on the Figures indicate assembly parts.

CONTENTS


1. CHASIS GROUP.....	1
2. STACKING GROUP	3
3. UPPER PULLER GROUP	5
4. REAR PULLER GROUP	7
5. THREAD STAND	9

1. CHASSIS GROUP




No.	Note	Parts No.	Description	Qty
1		DLN9010-WSU-01-001	CHASSIS	1
2		DLN9010-WSU-01-002	TABLE	1
3		PN-01-00000-07	REGULATOR	1
4		DLN9010-WSU-01-004	MACHINE HEAD	1
5		PN-1200000-01	BLOCK	1
6		PN-0300000-09	VALVE	2
7		DLN9010-WSU-01-007	CONNECTION BRACKET	1
8		DLN9010-WSU-01-008	FABRIC TRANSPORT SHEET	1
9		DLN9010-WSU-01-009	FABRIC TRANSPORT CONNECTION SHEET	1
10		EL-3400000-01	CONTROL BOX	1
11		HR-1800001-01	PEDAL SET	1
12		EL-2800000-04	CONTROL SWITCH	1
13		HR-1000000-02	RUBBER	4
14		HR-1400000-01	CASTER	4
15		PN-0200000-02	REGULATOR	1
16		PN-0600000-36	ELBOW	2
17		PN-0600000-35	ELBOW	5
18		PN-0300000-10	AIR ADJUSTMENT VALVE	1
19		EL-3500000-01	JUKI OPERATION PANEL	1

2.STACKING GROUP




No.	Note	Parts No.	Description	Qty
1		DLN9010-02-001	STACKING PROFILE	1
2		PN-0500000-03	PROFILE CAP	10
3		SP-0300000-01	EDGE BAND CONNECTION	4
4		SP-0200000-04	NUT	24
5		VD-6081202-TP	SCREW	24
6		DLN9010-02-006	PROFILE STABILIZING FOOT	2
7		DLN9010-02-007	STACKING CONNECTION BRACKET	2
8		DLN9010-02-008	STACKING TABLE	1
9		VD-1061602-TM	SCREW	2
10		DLN9010-02-010	UPPER UNSLIDE FABRIC	1

3.UPPER PULLER GROUP




No.	Note	Parts No.	Description	Qty
1		DLN-9010-WSU-03-001	UPPER PULLER MAIN BASE	1
2		DLN-9010-WSU-03-002	PULLER ARM	1
3		DLN-9010-WSU-03-003	SPECIAL SCREW	1
4		DLN-9010-WSU-03-004	SPRING	1
5		HR-0200000-04	NUT	1
6		RL-0100000-02	BEARING	2
7		DLN-9010-WSU-03-007	JUNCTURE CONNECTION SHAFT	1
8		SM-6050000-SM	NUT	1
9		DLN-9010-WSU-03-009	BUSHING	1
10		DLN-9010-WSU-03-010	BUSHING	1
11		DLN-9010-WSU-03-011	PULLER ARM	1
12		DLN-9010-WSU-03-012	GEAR	1
13		RL-0100000-11	BEARING	2
14		DLN-9010-WSU-03-014	SHAFT	1
15		DLN-9010-WSU-03-015	HEXAGON INTER-CONNECTION	2
16		PN-0400000-49	PULLER ARM MOVEMENT AIR CYLINDER	1
17		PN-0500000-10	FORK JOINT	1
18		DLN-9010-WSU-03-018	SHAFT	1
19		DLN-9010-WSU-03-019	CYLINDER CONNECTION BASE	1
20		DLN-9010-WSU-03-020	CONICAL SPRING	1
21		DLN-9010-WSU-03-021	SHAFT	1
22		DLN-9010-WSU-03-022	STRETCHING SHAFT	1
23		DLN-9010-WSU-03-023	GEAR	1
24		DLN-9010-WSU-03-024	SHAFT	1
25		TZ-0300210-10	TRIGGER BELT	1
26		DLN-9010-WSU-03-026	CONNECTION FOOT 01	1
27		DLN-9010-WSU-03-027	CONNECTION FOOT 02	1
28		DLN-9010-WSU-03-028	CONNECTION FOOT 03	1
29		DLN-9010-WSU-03-029	STABILIZNG FOOT	1
30		DLN-9010-WSU-03-030	PIN	1
31		DLN-9010-WSU-03-031	PULLER COVER	1
32		VD-3062002-TP	SCREW	3
33		PL-0641600-KM	WASHER	2
34		VD-6082002-TP	SCREW	1
35		SM-6080000-SM	SOMUN	1
36		VD-3051202-TP	SCREW	2
37		PL-0531000-KM	WASHER	2
38		VD-8030602-TP	SCREW	2
39		VD-6051602-TP	SCREW	1
40		VD-3061202-TP	SCREW	1
41		VD-8051002-TP	SCREW	3
42		PN-0600000-26	ELBOW	2

4.REAR PULLER ARM GROUP



No.	Note	Parts No.	Description	Qty
1		DLN9010-WSU-04-001	BOX CONNECTION EDGE BAND	1
2		DLN9010-WSU-04-002	TRANSPOSITION BOX	1
3		TK-0012828-21	TRIGGER GEAR	2
4		TZ-0100150-10	TRIGGER BELT	1
5		HR-0800000-01	U JUNCTURE	2
6		DLN9010-WSU-04-006	MOVEMENT SHAFT	1
7		DLN9010-WSU-04-007	STROKE SHAFT	1
8		DLN9010-WSU-04-008	GUARD COVER	1

5.THREAD STAND



No.	Note	Parts No.	Description	Qty
1		40108401	THREAD STAND	1

Company Name : JUKI SINGAPORE PTE LTD.
ADD : 20 BENDEMEER ROAD,#04-12 BS BENDEMEER CENTRE SINGAPRE 339914
PHONE : (65) 6553-4388
HTTP : <http://www.juki.com.sg>
E-Mail : we.sgp-sales@ml.juki.com

Company Name : JUKI Machinery Vietnam Company Ltd
ADD : 153 HOA LAN STR.,WARD 2, PHU NHUAN DIST., HO CHI MINH CITY, VIETNAM
PHONE : (84) 28-35178833
FAX : (84) 28-35178318
E-Mail : sales@jukimv.com

Company Name : JUKI Machinery Bangladesh Ltd
ADD : NATORE TOWER(5TH FLOOR) PLOT#32-D & 32-E, ROAD#2, SECOR#03 ,
 UTTARA MODEL TOWN, DHAKA, BANGLADESH
PHONE : (880)2-48954731
FAX : (880)2-48954733
E-Mail : vl.mbl-info@ml.juki.com

Company Name : JUKI India Private Limited
ADD : GAOUND AND 1ST FLOOR, NO.1090/I, 18TH CROSS ROAD,3RD SECTOR,
 HSR LAYOUT BANGALORE-560 102, KARNATAKA STATE, INDIA
PHONE : (91)80-4251-1900
FAX : (91)80-4251-1999
HTTP : <http://jukiindia.com>
E-Mail : jukiblr@jukiindia.com

Company Name : JUKI CENTRAL EUROPE
ADD : UL. POLECZKI 21(PLATAN PARK C) 02-822 WARSAW, POLAND
PHONE : (48)22-545-0400
FAX : (48)22-545-0411
HTTP : <http://jukieurope.com>

Company Name : JUKI America INC
ADD : 8500 NW 17TH STREET, SUITE 100, DORAL, FL 33126-1035, U.S.A.
PHONE : (1)305-594-0059
HTTP : <https://juki.com>

Company Name : JUKI MIDDLE EAST (JUKI SINGAPORE PTE. LTD. UAE BRANCH)
ADD : OFFICE NO, 2511. BLOCK A JAFZA 1, PO BOX 18031, JEBEL ALI, DUBAI UAE
PHONE : (971)4-8833228
FAX : (971)4-8833230
HTTP : <http://www.juki.com.sg>

Company Name : JUKI (China) CO LTD.
ADD : ROOM 901-903, HAILIANG BUILDING, NO.22, LANE 118 ZHONGJIANG ROAD,
 PUTUO DISTRICT SHANGHAI, CHINA, 200062
PHONE : 8621-6236-8888
HTTP : <http://www.jukichina.com>

**JUKI CORPORATION**

SEWING MACHINERY & SYSTEMS BUSINESS UNIT

2-11-1, Tsurumaki, Tama-shi, Tokyo 206-8551, Japan

Phone: (81) 42-357-2211

