

PARTS LIST

SC-952 PARTS LIST

下記 URL より、便利な検索機能のついた Web Parts List をご利用頂けます。

ご利用には会員登録が必要です。(無料)

<https://www.juki.co.jp/partslist/>

You can use a Web Parts List with a convenient search function from the URL below. To use this website, free membership registration is required.

<https://www.juki.co.jp/partslist/>

HOW TO MAKE USE OF THIS PARTS LIST

1.Explanation of codes

1)"*" mark.....means this part is changed from the previous parts book.

As to the details of the change, refer to "List for information of change".

2)"#01".....refer to "Note" explanation at bottom of page.

2.Codes on the "Qty" column

• Each numeral indicates the number of parts required.

• "0.1" and "2.5" indicate the length (in meters) of the respective parts.

3.Parentheses mean that the corresponding part is a subpart that constructs an assembly part.

4.Dotted lines on the Figures indicate assembly parts.

5.As to the parts with marks of "☆"(consumable parts) and "◎"(optional parts)on the respective parts,

it is recommended to prepare spares.

パーツリストご利用に際して

1."注記"欄の記号説明

1)"*"印..... 前回のパーツブックに比較して今回変更された部品を意味します。

変更内容は"変更情報リスト"を参照してください。

2)"#01"..... ページ下の"注記"の説明を参照してください。

2.数量欄の数字は、個数を表し、0.1、2.5等の数値は、長さ(単位メートル)を表します。

3.数量欄の()は、組部品を構成している子部品であることを意味します。

4.イラストページの-----枠は、組構成であることを意味します。

5.リストページの"☆"(消耗部品)、"◎"(オプション部品)の印がついた部品は、

予備を準備しておくことをお奨めします。

CONTENTS


目次

1. SC-952	1
SC - 952	
2. LIST FOR INFORMATION OF CHANGE.....	3
変更情報リスト	
NUMERICAL INDEX OF PARTS.....	4
索引	

1. SC-952

SC-952

1 ~ 4



REF.NO	NOTE	PART NO	DESCRIPTION	品名	Qty
1	#01	401-92550	PSC UNIT 1PHASE 220-240V	PSCユニット 単相220V~240V	1
2	#02	401-92551	PSC UNIT 3PHASE 200-240V	PSCユニット 三相200V~240V	1
3	#03	401-92552	PSC UNIT 1PHASE 100-120V	PSCユニット 単相100V~120V	1
4	#04	401-92553	PSC UNIT 1PHASE 220-240V CE	PSCユニット 単相220V~240V CE	1
5		401-94638	BOX_FRAME	ボックスフレーム	(1)
6		401-70984	BOX_COVER_CE	ボックスカバー	(1)
7		401-15877	MAIN_PLATE	メイン基板取付板	(1)
8		401-15874	FAN_PLATE	ファン取付板	(1)
9		401-43990	STUD	電装スタッド	(2)
10		401-71750	PLATE_B	コード出口板	(1)
11		401-75589	PLATE_C	電源コード取付板	(1)
12		401-15879	FAN_COVER	ファンカバー	(1)
13	*	402-63872	CTL PCB ASSY	CTL基板組	(1)
14	* #05	402-63877	PWR PCB ASSY	PWR基板組	(1)
15	* #04	402-63880	PWR-CE PCB ASSY	PWR-CE基板組	(1)
16	#01	401-86895	FLT-G PCB ASSY	FLT-G基板組	(1)
17	#04	401-69130	FLT-S PCB ASSY	FLT-S基板組	(1)
18	#06	401-69140	FLT-T PCB ASSY	FLT-T基板組	(1)
19		401-14398	MAIN COOL SHEET	MAIN冷却シート	(2)
20		401-70983	CTL-PWR S CORD ASSY	CTL-PWR Sコード組	(1)
21		401-75579	CTL-PWR P CORD ASSY	CTL-PWR Pコード組	(1)
22		401-75580	CTL-PWR T CORD ASSY	CTL-PWR Tコード組	(1)
23	#07	401-75581	FLT-PWR CORD ASSY (200V)	FLT-PWRコード組 (200V)	(1)
24	#03	401-75582	FLT-PWR CORD ASSY (100V)	FLT-PWRコード組 (100V)	(1)
25	#04	401-76825	FLT-PWR CORD ASSY (CE)	FLT-PWRコード組 (CE)	(1)
26		401-75583	FLT-CTL CORD ASSY	FLT-CTLコード組	(1)
27	#01	401-75586	AC INPUT CORD S ASSY	AC入力コードS組	(1)
28	#06	401-75587	AC INPUT CORD T ASSY	AC入力コードT組	(1)
29	#04	401-92564	AC INPUT CORD CE ASSY	AC入力コードCE組	(1)
30		401-12124	FAN MOTOR ASSY	ファンモータ組	(1)
31		EA-9500B01-00	CABLE BAND	束線バンド	(1)
32		KX-0000003-20	BUSH	ブッシュ	(1)
33		KX-0000002-60	SADDLE TYPE TIE MOUNT	サドルタイプタイマウント	(1)
34		HX-0022200-0D	WIRE SADDLE	ワイヤサドル	(1)
35		HX-0029200-0A	CABLE BAND	束線パーツ	(1)
36		HX-0015000-0A	CABLE CLAMP	ケーブルクリップ	(1)
37		SL-4040881-SC	SCREW M4 L=8	産金付きネジ M4 L=8	(1)
38		SL-4040881-SC	SCREW M4 L=8	産金付きネジ M4 L=8	(8)
39		SL-4040881-SC	SCREW M4 L=8	産金付きネジ M4 L=8	(5)
40		SL-4040881-SC	SCREW M4 L=8	産金付きネジ M4 L=8	(2)
41		SL-4040881-SC	SCREW M4 L=8	産金付きネジ M4 L=8	(2)
42		SL-4040881-SC	SCREW M4 L=8	産金付きネジ M4 L=8	(2)
43		SL-4040881-SC	SCREW M4 L=8	産金付きネジ M4 L=8	(2)
44		SL-4040881-SC	SCREW M4 L=8	産金付きネジ M4 L=8	(1)
45		SL-4040881-SC	SCREW M4 L=8	産金付きネジ M4 L=8	(1)
46		SL-4040881-SC	SCREW M4 L=8	産金付きネジ M4 L=8	(1)
47		SL-4040881-SC	SCREW M4 L=8	産金付きネジ M4 L=8	(8)
48		SL-4041081-SC	SCREW M4 L=10	産金付きネジ M4 L=10	(1)
49		SL-4041081-SC	SCREW M4 L=10	産金付きネジ M4 L=10	(4)
50		SL-4042091-SC	SCREW M4 L=20	産金付きネジ M4 L=20	(2)
51		WP-0430800-SC	WASHER M4	平産金小形丸 M4	(1)
52	#04	EA-9500B01-00	CABLE BAND	束線バンド	(5)
53		KN-0000000-70	CORES	コア	(1)
54		HX-0033900-0M	SPACER	スプーサ	(5)
55	#08	CM-3001000-01	VOLTAGE WARNING LABEL (31.5)	危険電圧警告シール (31.5)	(1)
56	#06	CM-3004000-02	VOLTAGE DANGER LABEL 3 (SMAL)	危険電圧シール 3 (小)	(1)
57	#09	CM-3004006-02	VOLTAGE CAUTION LABEL L=25	電圧注意シール L=25	(1)
58	#04	CM-6001001-01	WE E E MARK LABEL S	WE E E マーク ラベル S	(1)
59	#04	401-50131	EAC_MARK_LABEL_S	E A C マークラベル S	(1)
60		SL-4041281-SC	SCREW M4 L=12	産金付きネジ M4 L=12	(4)
61		M8002-430-000	STOPPER	ねじストッパー	(4)
62		401-41206	RESISTANCE_A_ASSY	回生抵抗組	(1)
63		EA-9500B01-00	CABLE BAND	コア用束線バンド	(1)
64		EA-9500B01-00	CABLE BAND	束線バンド	(1)
65	#04	HN-0024100-00	CORES	コア用フェイラ	2
66	#04	HN-0024600-00	CORES	フェライトクラップ	3
67	#04	HN-0035600-00	CORES	コア	2
68	#04	CM-6001002-01	WE E E INFORMATION SHEET	WE E E インフォメーション シート	1
69	#01	401-11651	POWER SWITCH ASM	電源スイッチ組	1
70	#02	401-18323	POWER SWITCH ASSY	電源スイッチ組 三相	1
71	#07	SK-3512001-SE	WOOD SCREW D=5.1 L=20	丸木ねじ D=5.1 L=20	2
72		400-88314	CONNECTING_ROD_ASSY	連結棒組	1
73		M3004-511-00A	VOLTAGE INDICATION CARD	電圧表示カード	1
74		HF-0013050-0P0	SLO-BLO FUSE	タイムラグヒューズ	1
75		EA-9500B02-00	CABLE BAND	束線バンド	2
76		MAO-11532000	CORD STAPLE	コードステップル	2
77		SL-6084092-TN	BOLT	産金付き六角穴ボルト	4
78		HX-0051000-00	OMEGALOCK	オメガロック	2
79		401-92573	PEDAL SENSOR BASE SP ASSY	ペダルセンサベース (分離) 組	1
80		401-92574	PEDAL SENSOR SP ASSY	ペダルセンサ組	(1)
81		401-92575	PEDAL SENSOR COIL HOLD ASSY	ペダルセンサコイル取付板組	(1)
82		401-92576	PEDAL SENSOR COIL ASSY	ペダルセンサコイル組	(1)
83		400-42136	COIL_BASE	コイルベース	(1)
84		400-52809	NYLON_RIVET	ナイロンリベット	(2)
85		EA-9500B01-00	CABLE BAND	束線バンド	(1)
86		401-70980	PEDAL_SENSOR_BASE	ペダルセンサベース	(1)
87		400-42131	PEDAL_LEVER	ペダルレバー	(1)
88		401-77068	PEDAL_LEVER_FG	ペダルレバーFG	(1)
89		400-06202	ADJUST_NUT	調節ナット	(2)
90		400-06207	FRONT_SPRING	前部ばね	(1)
91		400-06208	SPRING_SHAFT_A	ばね軸A	(2)
92		400-49428	SPRING_C	ばね軸C	(2)
93		400-06212	ADJUST_SCREW	調節ねじ	(2)
94		SM-8040612-TP	SCREW M4 L=6	止めねじ M4 L=6	(2)
95		SV-4030601-SR	SCREW M3 L=6	産付きタピンねじ	(2)
96		401-70964	PEDAL_SENSOR_BRACKET	ペダルセンサ取付板	(1)
97		SL-4051281-SC	SCREW M5 L=12	産金付きネジ M5 L=12	(3)
98		HN-0028400-00	CORES	フェライトコア	(1)
99		EA-9500B01-00	CABLE BAND	束線	(2)
100		WP-0612056-SD	WASHER 6 X18.5X2	ワッシャー 6 X 18.5 X 2	2
101		ST-9053511-SR	TAPPING SCREW M5X35	タップピンねじ	2
102		WP-0651646-SC	WASHER	平産金	4
103		401-94296	RUBBER_CUSHION_BRKT	防振ゴム取付板	2
104		401-65702	RUBBER_CUSHION	防振ゴム	4
105		NM-6060001-SC	NUT M6X1 TYPE1	六角ナット M6 X 1 1種	4
106		WT-0640001-KN	TOOTH WASHER	歯付き産金 A6	4
107	#04	M6102-461-DA	AC INPUT CABLE ASM (CE)	AC入力ケーブル組 (CE)	1
108	#04	401-79371	REACTOR_BOX_ASSY_1P	リアクタボックス組 1P	1
109		401-61413	REACTOR_BOX_COVER_A_ASSY	リアクタボックスカバーA組	(1)
110		401-61414	REACTOR_BOX_BASE	リアクタボックス取付板組	(1)
111		SL-4040881-SC	SCREW M4 L=8	産金付きネジ M4 L=8	(4)
112		401-79372	REACTOR PCB ASSY 1P	リアクタ基板組 1PCS	(1)
113		SL-4040881-SC	SCREW M4 L=8	産金付きネジ M4 L=8	(6)
114		HX-0015000-0B	CABLE CLAMP	ケーブルクリップ	(2)
115		SL-4040881-SC	SCREW M4 L=8	産金付きネジ M4 L=8	(2)
116		SL-4040881-SC	SCREW M4 L=8	産金付きネジ M4 L=8	(2)
117		M1015-110-000	CORD_BUSH_A	コードブッシュ A	(1)
118		CM-3001000-03	VOLTAGE WARNING LABEL (25)	危険電圧警告シール (25)	(1)
119		CM-3004006-02	VOLTAGE CAUTION LABEL L=25	電圧注意シール L=25	(1)
120	#04	HX-0006500-0A	CABLE BAND	束線バンド	1
121	#04	401-62979	REACTOR_BOX_ACCESSORY	リアクタボックス付属品	1
122		SK-3512001-SE	WOOD SCREW D=5.1 L=20	丸木ねじ D=5.1 L=20	(4)
123		MAO-11532000	CORD STAPLE	コードステップル	(4)
124		401-92560	SC952 USE INSTRUCTION 10K	SC952使用注意書 10K	1
125	#04	401-92561	CORE SETUP MANUAL	コア取付マニュアル	1
126	#04	HX-0015000-0L	CABLE CLIP	ケーブルクリップ	1
127	#04	SK-3512001-SE	WOOD SCREW D=5.1 L=20	丸木ねじ D=5.1 L=20	1
		NOTE (注記)	#01...FOR 1-PHASE 220~240V #02...FOR 3-PHASE 200~240V #03...FOR 1-PHASE 100~120V #04...FOR 1-PHASE 220~240V CE #05...EXCEPT 1-PHASE 220~240V CE #06...FOR 3-PHASE 220~240V FOR 1-PHASE 100~120V #07...FOR 3-PHASE 220~240V FOR 1-PHASE 220~240V #08...FOR 1-PHASE 220~240V 1-PHASE 220~240V CE #09...EXCEPT 1-PHASE 100~120V	単相 220~240V 用 三相 200~240V 用 単相 200~240V 用 単相 220~240V CE 用 単相 220~240V CE を除く 単相 200~240V 用 単相 100~120V 用 単相 200~240V 用 単相 200~240V 用 単相 220~240V 用 単相 220~240V CE 用 単相 100~120V を除く	

2. LIST FOR INFORMATION OF CHANGE

変更情報リスト

As to the place changed, refer to the corresponding Rev. No.
 When previous parts (Obsoleted part) and new parts (Added parts) are not interchangeable with each other:
 In this case, even obsoleted parts (D.) can be ordered with the obsoleted part number, so select the parts with changed dates and place your orders.

変更箇所は、該当 Rev. No. 版をご参照ください。
 部品の互換性がない変更の場合は、削除された品番でも、ご注文できます。

No. 1713-01・・・Rev. No.

*A: Added parts追加部品 / D: Obsoleted parts削除部品 / E: Erratum訂正

*	Rev. No.	Page 頁	Ref. No.	Parts No. 品番	*	Rev. No.	Page 頁	Ref. No.	Parts No. 品番
	D 00	2	13	401-86250		A 01	2	13	402-63872
	D 00	2	14	401-86260		A 01	2	14	402-63877
	D 00	2	15	401-86356		A 01	2	15	402-63880

NUMERICAL INDEX OF PARTS

索引

PART NO 品番	PAGE 頁	REF NO	PART NO 品番	PAGE 頁	REF NO	PART NO 品番	PAGE 頁	REF NO	PART NO 品番	PAGE 頁	REF NO
CM-3001000-01	2	55	400-06202	2	89						
CM-3001000-03	2	118	400-06207	2	90						
CM-3001004-02	2	56	400-06208	2	91						
CM-3004006-02	2	57	400-06212	2	93						
CM-3004006-02	2	119	400-42131	2	87						
CM-6001001-01	2	58	400-42136	2	83						
CM-6001002-01	2	68	400-49426	2	92						
			400-52809	2	84						
EA-9500B01-00	2	31	400-88314	2	72						
EA-9500B01-00	2	52	401-11214	2	30						
EA-9500B01-00	2	63	401-11651	2	69						
EA-9500B01-00	2	64	401-14398	2	19						
EA-9500B01-00	2	85	401-15874	2	8						
EA-9500B01-00	2	99	401-15877	2	7						
EA-9500B02-00	2	75	401-15879	2	12						
			401-18323	2	70						
HF-0013050-P0	2	74	401-41206	2	62						
HN-0024600-00	2	66	401-43990	2	9						
HN-0028400-00	2	98	401-50131	2	59						
HN-0035600-00	2	67	401-61413	2	109						
HN-0042100-00	2	65	401-61414	2	110						
HX-0006500-OA	2	120	401-62979	2	121						
HX-0015000-OA	2	36	401-65702	2	104						
HX-0015000-OB	2	114	401-69130	2	17						
HX-0015000-OL	2	126	401-69140	2	18						
HX-0022200-OD	2	34	401-70964	2	96						
HX-0029200-OA	2	35	401-70980	2	86						
HX-0033900-OM	2	54	401-70983	2	20						
HX-0051000-00	2	78	401-70984	2	6						
			401-71750	2	10						
KN-0000000-70	2	53	401-73469	2	11						
KX-0000002-60	2	33	401-75579	2	21						
KX-0000003-20	2	32	401-75580	2	22						
			401-75581	2	23						
MAO-11532000	2	76	401-75582	2	24						
MAO-11532000	2	123	401-75583	2	26						
M1013-110-000	2	117	401-75586	2	27						
M3004-511-00A	2	73	401-75587	2	28						
M6102-461-DAA	2	107	401-76825	2	25						
M8002-430-000	2	61	401-77068	2	88						
			401-79371	2	108						
NM-6060001-SC	2	105	401-79372	2	112						
			401-86895	2	16						
SK-3512001-SE	2	71	401-92550	2	1						
SK-3512001-SE	2	122	401-92551	2	2						
SK-3512001-SE	2	127	401-92552	2	3						
SL-4040881-SC	2	37	401-92553	2	4						
SL-4040881-SC	2	38	401-92560	2	124						
SL-4040881-SC	2	39	401-92561	2	125						
SL-4040881-SC	2	40	401-92564	2	29						
SL-4040881-SC	2	41	401-92573	2	79						
SL-4040881-SC	2	42	401-92574	2	80						
SL-4040881-SC	2	43	401-92575	2	81						
SL-4040881-SC	2	44	401-92576	2	82						
SL-4040881-SC	2	45	401-94296	2	103						
SL-4040881-SC	2	46	401-94638	2	5						
SL-4040881-SC	2	47	402-63872	2	13						
SL-4040881-SC	2	111	402-63877	2	14						
SL-4040881-SC	2	113	402-63880	2	15						
SL-4040881-SC	2	115									
SL-4040881-SC	2	116									
SL-4041081-SC	2	48									
SL-4041081-SC	2	49									
SL-4041281-SC	2	60									
SL-4042091-SC	2	50									
SL-4051281-SC	2	97									
SL-6084092-TN	2	77									
SM-8040612-TP	2	94									
ST-9053511-SR	2	101									
SV-4030601-SR	2	95									
WP-0430800-SC	2	51									
WP-0612056-SD	2	100									
WP-0651646-SC	2	102									
WT-0640001-KN	2	106									