
How to Install the belt cover for
LH-1100 SERIES, DNU SERIES
LU-1114 SERIES, LZH SERIES
MH SERIES, LUH SERIES

ベルトカバー取付書

NO. 00
29182508

ミシンを使用する前に付属のねじを用いてベルトカバーを図のように必ず取り付けること。

Before putting the machine into service, the belt cover has to be attached to the machine head using screw enclosed in this bag as illustrated the figure.



ミシンを倒すときは、木ねじをゆるめベルトカバーを矢印方向に止まるまで移動させてから倒して下さい。

Incline the machine head after loosening the wood screw and moving the belt cover to the extreme in the direction shown by the arrow.

