

PARTS LIST

MC37,40 PARTS LIST

下記 URL (PARTS Website/PC サイト) より、便利な検索機能のついた Web Parts Book をご利用頂けます。
ご利用には会員登録が必要です。(無料)

<https://juki.aftama.com/JUKI/JA>

You can use a Web Parts Book with a convenient search function from the URLs (PARTS Website/PC-site)
below. To use the PARTS Website, free membership registration is required.

<https://juki.aftama.com/JUKI/EN>


HOW TO MAKE USE OF THIS PARTS LIST

- 1.As to "#01" and "#02" refer to the "Note" given at the bottom of the respective pages.
- 2.Codes on the "Qty" column
 - Each numeral indicates the number of parts required.
 - "0.1" and "2.5" indicate the length (in meters) of the respective parts.
- 3.Parentheses mean that the corresponding part is a subpart that constructs an assembly part.
- 4.Dotted lines on the Figures indicate assembly parts.

CONTENTS


1. MC-37C	1
2. MC-40	3
NUMERICAL INDEX OF PARTS	5

1. MC-37C



REF.NO	NOTE	PART NO	DESCRIPTION	Qty
1		700-04978	MC37_C	1
2		700-04979	WASTE_REVEMOVE_ASSY	(1)
3		700-04980	WASTE_REVEMOVE_BODY	(1)
4		700-04981	HOSE_CLAMP	(4)
5		700-04982	HOSE	(1)
6		700-04983	BOND	(1)
7		700-04984	REDUCING_ADAPTOR	(1)
8		700-04985	BRACKET	(1)
9		700-04986	BOLT	(2)
10		700-04987	NUT	(2)
11		700-04988	NEEDLE_VALVE	(1)
12		700-04989	MUFFLER	(1)
13		700-04990	WASTE_BAG_ASSY	(1)
14		700-04991	WASTE_BAG	(1)
15		700-04992	WASTE_BAG_COVER	(1)
16		700-04993	SCREW	(5)
17		700-04994	BOLT	(4)
18		700-04995	NUT	(4)
19		700-04996	COVER_BRACKET	(1)
20		700-04997	SOL_VALVE_ASSY	(1)
21		700-04998	SCREW	(2)
22		700-05000	TUBING	(1)
23		401-90365	SOL_VALVE_ASSY	(1)
24		401-89715	SOL_VALVE	(1)
25		401-88368	AIR SOLENOID RELAY CABLE ASSY	(1)
26		700-05001	TEE_UNION	(2)

2. MC-40



REF.NO	NOTE	PART NO	DESCRIPTION	Qty
1		400-23707	MC40	1
2		400-23665	WASTE REMOVER ASSY	(1)
3		400-23667	HOSE CLAMP	(4)
4		400-23668	FLEXIBLE HOSE	(1)
5		GMC-38013000	SCR TRUSS PHIL TAP	(2)
6		400-23669	TUBE CLIP	(2)
7		400-23670	MOUNTING PLATE	(1)
8		400-23671	SCREW	(2)
9		F1033-003-000	NUT	(2)
10		GMC-08016000	NEEDLE VALVE	(1)
11		400-23692	BRASS BARB CONNECTOR	(1)
12		400-23672	REDUCING ADAPTOR	(1)
13		400-23666	WASTE REMOVER BODY	(1)
14		400-23673	MUFFLUR ASSY	(1)
15		400-23674	MUFFLER	(1)
16		400-23667	HOSE CLAMP	(1)
17		400-23675	WASTE BAG ASSY	(1)
18		400-23677	WASTE BAG BRACKET	(1)
19		400-23678	WASTE BAG	(1)
20		400-23679	FENDER WASHER	(1)
21		400-23680	SCREW	(1)
22		400-23681	PUSH IN FASTNER	(1)
23		400-23682	LOCKNUT	(1)
24		400-23683	SCREW HEX SLOT WASHER	(2)
25		400-23684	TUBE CAP 0.75	(1)
26		GMC-08024000	HOSE CLAMP	(1)
27		400-23676	WASTE BAG HOUSING	(1)
28		400-23700	TREADLE SWITCH ASSY	(1)
29		GMC-08052000	SHAFT	(2)
30		400-23688	SHAFT COLLAR 0.25	(2)
31		GMC-08012000	FIXED SCREW 8-32 UNF L=6	(5)
32		GMC-08051000	SPRING	(1)
33		400-23689	VALVE STEM DEPRESSOR	(1)
34		400-23690	PLUG 0.625	(1)
35		400-23691	NYLON VALVE HOUSING	(1)
36		400-23692	BRASS BARB CONNECTOR	(1)
37		400-23693	FLOW CONTROL PIN	(2)
38		400-23694	BRASS EL BARBED	(1)
39		400-23695	DOWEL PIN	(3)
40		400-23696	CARTRIGE VALVE 3-WAY	(1)
41		400-23697	VALVE LEVER	(1)
42		400-23698	PUSH ON RETAINER WASHER	(2)
43		400-23699	POLY TUBING 0.25 6MM	(1)
44		GMC-08005000	BALL JOINT	(2)
45		400-23708	UNION TEE AUTO	(1)

NUMERICAL INDEX OF PARTS

PART NO	PAGE	REF NO	PART NO	PAGE	REF NO	PART NO	PAGE	REF NO	PART NO	PAGE	REF NO
F1033-003-000	4	9									
GMC-08005000	4	44									
GMC-08012000	4	31									
GMC-08016000	4	10									
GMC-08024000	4	26									
GMC-08051000	4	32									
GMC-08052000	4	29									
GMC-38013000	4	5									
400-23665	4	2									
400-23666	4	13									
400-23667	4	3									
400-23667	4	16									
400-23668	4	4									
400-23669	4	6									
400-23670	4	7									
400-23671	4	8									
400-23672	4	12									
400-23673	4	14									
400-23674	4	15									
400-23675	4	17									
400-23676	4	27									
400-23677	4	18									
400-23678	4	19									
400-23679	4	20									
400-23680	4	21									
400-23681	4	22									
400-23682	4	23									
400-23683	4	24									
400-23684	4	25									
400-23688	4	30									
400-23689	4	33									
400-23690	4	34									
400-23691	4	35									
400-23692	4	11									
400-23692	4	36									
400-23693	4	37									
400-23694	4	38									
400-23695	4	39									
400-23696	4	40									
400-23697	4	41									
400-23698	4	42									
400-23699	4	43									
400-23700	4	28									
400-23707	4	1									
400-23708	4	45									
401-88368	2	25									
401-89715	2	24									
401-90365	2	23									
700-04978	2	1									
700-04979	2	2									
700-04980	2	3									
700-04981	2	4									
700-04982	2	5									
700-04983	2	6									
700-04984	2	7									
700-04985	2	8									
700-04986	2	9									
700-04987	2	10									
700-04988	2	11									
700-04989	2	12									
700-04990	2	13									
700-04991	2	14									
700-04992	2	15									
700-04993	2	16									
700-04994	2	17									
700-04995	2	18									
700-04996	2	19									
700-04997	2	20									
700-04998	2	21									
700-05000	2	22									
700-05001	2	26									